






DAISY














Tabela				
Nr	X mm	Y mm	Z mm	Szt.
1	1120	375	16	1
2	755	400	16	1
3	1120	375	16	1
4	718	80	16	5
5	746	358	2,5	3
6	205	746	16	5
7	130	350	16	5
8	130	660	16	5
9	130	350	16	5
10	355	690	2,5	5

x5






A  54 x Ø8x35	B  22 x Ø15x12	B1  22 x 34mm	B2  22 x Ø17	B3  10 x Ø7x50	B4  10 x Ø12
C  20 x Ø3,5x13	C1  20 x Ø3x20	C2  10 x Ø3x25	C4  78 x Ø4x16	D1  10 x 500mm	D2  10 x 500mm
		E  5 x 128mm	H4  48 x	J  4 x	Z  1 x

I





II






V



VI





VII

WAŻNE / IMPORTANT!

W celu zapewnienia bezpieczeństwa zalecany jest montaż mebla do ściany za pomocą zestawu zawartego w akcesoriach.



It is recommended to mount the furniture to the wall using the set included in the accessories.

Y=X




VIII


x5



IX



X



XI

